



Contemporary
Lighting™

Assembly Instruction For **EP96087-146**

1. Insert the G9 bulb(I) into socket(H)
2. Through the Socket(H) to the Cap(G)/Smaller Glass(F) /Large Glass(E) /Rubber Washer(D)/Metal Washer(C); then secured by Metal Part(B) till tighten
3. Thread the Tube(A) to the Metal Part(B) till tighten
4. Please see the another page that it is show how to assemble the Jack

